

Suggested Spare Parts for BRG-540 series Generator Sets for four years / 8000 Hrs average operation

1 - 4

Item	Part No.	Description	Qty.
1	XB-998209	Oil Filter	8/unit
2	XB-998162-2	Fuel Filter	8/unit
3	XB-998162-4	Seal Service Kit for Fuel Filter	3
4	K26 25145 112	V-Belt Cooling Fan	2/unit
5	K26 25145 113	Gasket Cylinder Head Cover	1/unit
6	K26 25145 114	Gasket Cylinder Head	1
7	XB-540041-01	Hose Radiator Inlet (top tank)	3
8	XB-540041-02	Hose Radiat Outlet (bottom tank)	3
9	XB-994130	Temperature Gauge	1
10	XB-994129	Temperature Sender	1
11	XB-998207	High Temperature Switch	1
12	XB-994020	Oil Pressure Gauge	1
13	XB-998208	Low Oil Pressure Switch	1
14	K26 25145 115	Glow Plug	2
15	XB-998214	Control Resistor - Glow Plugs	1
16	K26 25145 116	Cooling Pump Assy	2
17	K26 25145 117	Gasket Coolin Pump	2
18	K26 25145 118	Thermostat	2
19	XB-998206	Stop Solenoid	1
20	XB-998203	Starter Motor 12V	1
21	K26 25145 119	Alternator Batt Charging	1
22	XB-997878	Main Power Alternat 15kW/480V	1
23	XB-997880	Rectifier Assy Main Power Altern	3
24	XB-998205	Fuel Pump Electrical	2
25	XB-994040	Switch ON - OFF	2
26	XB-994042	Switch START - PREHEAT	2
27	XB-994001	Amp-Meter 12V	1
28	XB-994003	Volt-Meter 0 - 600VAC	1
29	XB-994081	Hour-Meter	1
30	XB-994008	Circuit Breaker 25A / 12VDC	1
31	XB-994072A	Relay Solid State Fuel Control	2
32	XB-216242	Electronic Cntrl Unit - Circ Board	1
33	XB-216184	Current Sensor Board 3 Phases	1
34	XB-994067	Main Load Circ Breaker 3x480V	1
35	K28 10785 01	Boot Plastic Main Circ Breaker	1/unit
36	XB-285151-01	Power Receptacle Assy	2
37	XB-995014	Glass Control Box Door	1
38	XB-999093	Expansion Tank Coolant	1
39	XB-999094	Cap Expansion Tank	2
40	XB-998059	Cap Fuel Tank	1
41	XB-999003-01	Rubber Latch Door Closing	12
42	XB-999003-02	Keeper Rubber Latch	4

43	XB-994160	Microswitch Power Recept Assy	2
44	XB-994128	Relay 12VDC	1