

## Suggested Spare Parts for NMG-112-05 Generator Sets for five years / 5000 Hrs average operation

1 - 4

| Itm. | Part No.      | Description                       | Qty.    |
|------|---------------|-----------------------------------|---------|
| 1    | K26 25150 100 | Oil Filter                        | 10/unit |
| 2    | XB-998162-2   | Cartridge Primary Fuel Filter     | 5/unit  |
| 3    | XB-998162-4   | Seal Serv Kit Prim Fuel Filter    | 4       |
| 4    | K26 25150 104 | Cartridge Secondary Fuel Filer    | 10/unit |
| 5    | K26 25150 105 | Bowl Secondary Fuel Filter        | 3       |
| 6    | K26 25150 106 | O-Ring Secondary Fuel Filter      | 5       |
| 7    | K26 25102 00  | Cartridge Air Filter              | 10/unit |
| 8    | K26 25100 00  | Safety Air Filt Cartridge if used | 10/unit |
| 9    | K26 25150 101 | Belt Cooling Fan                  | 1/unit  |
| 10   | K26 25150 107 | Gasket Rocker Arm Cover           | 1/unit  |
| 11   | K26 25150 108 | Gasket Cylinder Head              | 2       |
| 12   | 060 13997 01  | Hose Radiator Inlet (top tank)    | 1/unit  |
| 13   | 060 13998 01  | Hose Radiator Outlet (bottom)     | 1/unit  |
| 14   | XB-994130     | Temperature Gauge                 | 2       |
| 15   | XB-994129     | Temperature Sender                | 2       |
| 16   | K26 25150 109 | High Temperature Switch           | 2       |
| 17   | K26 24934 00  | Oil Pressure Gauge                | 2       |
| 18   | K26 24935 00  | Oil Pressure Sender               | 2       |
| 19   | K26 25111 126 | Oil Pressure Switch               | 2       |
| 20   | K26 25150 110 | Pump Assembly Cooling             | 2       |
| 21   | K26 25150 111 | Gasket Cooling Pump               | 2       |
| 22   | K26 25150 112 | Thermostat                        | 2       |
| 23   | K26 25150 113 | Stop Solenoid                     | 2       |
| 24   | K26 25150 114 | O-Ring Stop Solenoid              | 2       |
| 25   | K26 25150 115 | Starter Motor 12V                 | 1       |
| 26   | K26 25150 116 | Starter Solenoid 12V              | 1       |
| 27   | K26 25150 117 | Alternat. Battery Charging 12V    | 1       |
| 28   | K26 25150 118 | Brush Assy Batt Charg Altern      | 3       |
| 29   | K24 22380 00  | Main Power Alternator             | 1       |
| 30   | K24 22380 100 | Electronic Voltage Regulator      | 1       |
| 31   | XB-994108     | Diode Main Power Alternator       | 6       |
| 32   | XB-998205     | Fuel Pump Electrical              | 2       |
| 33   | XB-994158     | Temp & Oil Press Shut Down        | 1       |
| 34   | XB-994040     | Switch ON-OFF                     | 2       |
| 35   | XB-994042     | Switch Start Preheat              | 2       |
| 36   | XB-994001     | Amp-Meter 12V                     | 1       |
| 37   | XB-994003     | Voltmeter 0-600VAC                | 1       |
| 38   | K24 22121 00  | Relay 12VDC                       | 4       |
| 39   | XB-994008     | Circuit Breaker 25A-12VDC         | 1       |
| 40   | K24 22098 00  | Circ Breaker 480V/25A-3Pole       | 2       |
| 41   | K28 10785 01  | Boot Plastic Main Circ Brkr       | 2/unit  |
| 42   | K25 22099 00  | Hour Meter                        | 1       |
| 43   | K25 23732 00  | Power Receptacle                  | 2       |
| 44   | K25 26330 11  | Lamp Indicator (LED) Red          | 2       |
| 45   | K25 26330 13  | Lamp Indicator (LED) Green        | 2       |
| 46   | K28 10995 010 | O-Ring Indicator Lamp             | 4       |
| 47   | XB-998059     | Cap Fuel tank                     | 1       |
| 48   | K26 25111 151 | Radiator Cooling                  | 1       |
| 49   | K26 25111 164 | Tank Plastic Coolant expansion    | 1       |